



Trim flush & round sides

Put Ski Template in place prior to forming laminate. Remove when glue is dry.

Smear thin layer of weather proof wood glue between sheets  
 Attach to sled immediately before glue sets

